

QuickTime™ and a  
TIFF (Uncompressed) decompressor  
are needed to see this picture.



#### Parts List:

-1 double pulley    -1 single pulley    -2 DrynHigh End Support    -5 Wooden Lathes    -30' Rope  
-1 Cleat    -2 Self tapping screws

#### Installation Tools Needed:

-5/32" Drill Bit    -7/32" Drill    -Electric Drill    -Phillips head screw driver    -Stud Locator

#### Installation

- Using the stud locator, locate your ceiling joists to mount the screw pulleys. Your joists will run parallel or perpendicular to your installation location. Mark the location of your pulleys approx 48" apart.
- Using the electric drill and 7/32" drill bit, drill 1" deep into the ceiling. Using the 5/32" drill bit, drill 2 ½ " deep into the same hole. Repeat this step for the second pulley.
- Before installing the pulleys lubricate the pulley threads with dish soap or olive oil. Screw the pulleys into the previously drilled holes making sure the double pulley is on the same side the cleat will be mounted. **(Note: If the ceiling joists are particularly hard or you are having difficulty screwing in the pulley, stop and enlarge the holes slightly. Do not apply excess leverage to the pulley, this may break the casting or threaded stud.)**
- Assemble the 5 wooden lathes into the DrynHigh end supports, spacing the end supports the same distance as your pulleys (approx. 48")
- Take one end of the 30' rope and pass it through the double pulley and then through the single pulley. Take the other end and pass it through the double pulley only. Pass each end through the top hole in the end support and tie a simple knot. Pull the knot back into the large hole (so it is hidden).
- Using the screws provided, locate a wall stud using the stud locator and mount the cleat vertically. **It is important that the cleat is mounted to a secure location because it will be carrying a full load of laundry. Please mount the cleat high enough so it is out of reach of small children.**
- Note: An additional double pulley can be ordered to extend the rope away from DrynHigh and then to the cleat.
- Adjusting DrynHigh: It is suggested that you tie two knots into the rope that will be cleated off. Before tying the knots make sure the DrynHigh is level. One knot should be high for the raised position and the other lower for the comfortable down position. These knots should hook onto the cleat.

[www.drynhigh.com](http://www.drynhigh.com)  
183 Nostalgia Lane Bozeman, MT 59715  
406-624-6177